



Digital Vent Guage Installation Documentation

For questions regarding installation instructions as well as an install video, please visit www.p3cars.com/support.

WARRANTY & LIABILITY Neither P3 Cars, VEI Systems, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 1 year from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts. Warranty void if product is damaged from improper use. For off-road use only.

Wiring Diagrams (Non-Plug and Play Only)

Follow the instructions and install video for removing your center console, and get some 20 gauge wire to use to extend the power, ground, and dimmer wires down to the ashtray area.

Hook the gauge wires to the extension wire, and then use tap-ins to tap the wires in the car as shown in the instructions and on these diagrams. Wire directly to each wire, careful not to cross or short any connections.

