



For additional install
information please visit
www.p3gauges.com/install

Audi 8S TT Vehicle Installation



1 Plug the gauge into the vehicle's OBD2 port and start engine to test functionality before installation



2 Use a trim pry tool to remove the panel on the driver's side of the dash.



3 Use a trim pry tool to remove the defrost vent from the dash



4 Push display cable through the 4th gap from bottom as shown

WARRANTY & LIABILITY:
Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.



5a Insert clip into the 6th gap as shown



5b Press the clip into place on the defrost vent



For additional install
information please visit
www.p3gauges.com/install



5c The front of the display should align with the front edge of the vent when installed



6 Insert the end of the display cable to the hole between the dash and the air plenum as shown above



7 Pull cable out the hole on the side of the dash



8 Align display cable so that it fits between the plenum and the defrost vent

WARRANTY & LIABILITY:
Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.



9 Clip the vent back into place in the dash



10 Feed OBD2 cable from under the dash through the hole on the side of the dash



For additional install
information please visit
www.p3gauges.com/install



11 Connect both the display cable and the main harness to the control box



12 Tuck control box and wires into side dash



13 Replace side dash panel



14 Plug the OBD2 cable into the vehicle's OBD2 port

WARRANTY & LIABILITY:
Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.



Your installation is now complete