P3 GAUGES

For additional install information please visit www.p3gauges.com/install

1   Remove vent from vehicle.

2   Use a small screwdriver or pry tool to remove vent slat assembly from vent housing.

3   Remove center vent slat and reinstall it into bottom vent slat position.

4   When installing vent slat be sure to line up control fork with vertical slat pin. Feed the ribbon cable through the vent as shown.

WARRANTY & LIABILITY: Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.

5   Install display into vent housing.

6   Cut foam away from vent housing and feed cable through as shown.

You can now reinstall into vehicle.