



For additional install information please visit www.p3gauges.com/install

C7 Corvette Vehicle Installation



1 Plug the gauge into the vehicle's OBD2 port and start engine to test functionality before installation



2 Remove trim piece from passenger side of center stack



3 Remove 2 Torx screws from passenger side of center stack



4 Remove dash trim that goes over gauge cluster and center stack

WARRANTY & LIABILITY: Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.



5 Remove screws as shown



6 Remove 2 screws from lower dash, below steering wheel



For additional install information please visit www.p3gauges.com/install



7 Remove console trim and set aside



8 Remove rocker panel trim



9 Remove screw behind trim panel next to door



10 Set aside small aluminum trim

WARRANTY & LIABILITY: Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.



11 Pull lower dash away to gain access to screw



12 Remove dash trim screw as shown



For additional install information please visit www.p3gauges.com/install



13 Pull left side of dash out enough to gain access to back of vent (Right side of dash does not need to be fully removed.)



14 Release 4 tabs connecting vent to dash trim (outer two shown)



15 Remove vent, install display and route cable to OBD2 port. (if you did not purchase your gauge pre-installed in an OEM vent reference our display install PDF)

WARRANTY & LIABILITY:
Neither P3 Cars, nor its dealers or agents shall be liable in any way, for any damage, loss, injury or other claims, resulting from the installation or use of this product. By purchasing or installing this product, you assume all liability of any kind connected with the use and/or application of this product. If you are unsure that you can safely install and use this product, consult a qualified installer or mechanic. The warranty on this product covers only the product itself for a period of 6 months from the date of purchase, and it will be at our discretion to repair or replace the affected parts. No user serviceable parts inside. Warranty will be voided if product shows physical damage.

Follow steps in reverse order to install your gauge

